

**HONDA CRV IV-WM9FN Installation Manual**

Step 1 – Remove Driver side window switch using the provided dashboard removal tools




Step 2 – Remove existing connectors to window switch

Step 3 – Clip on the Mirror module to Window switch (You will hear it click into place)



**Step 4 – Connect the following cables in order**

1. Aux module connector
2. Window Control Unit Connector
3. Vehicle Wire Harness Connector




\* Confirm all connectors are securely connected before turning on the vehicle

**Step 6 – Test functionality and if everything is working as intended, proceed to clip back the Window switch back to door panel**

Infinity Vision Australia : ABN 32 626 985 151

**Module switch guide**



Switch Setting	1	2	3	4	5
On (Up)					
Off (Down) - Default	●	●	●	●	●

- 1. Mirror Folding function
- 2. Emergency door unlocking – Doors unlock upon sudden braking
- 3. Door Lock function
- 4. Door unlock function on Engine off (default)/ Door unlock on gear set to "P"
- 5. Doors lock on reaching 15km/h (default) / Doors lock on gear set to "D"